

RELAYCARD LS12-REL-DIN


Connection

Terminal C: Indication-outputs

<u>Signal</u>	<u>Connection</u>
1	C13
2	C12
3	C11
„	„
„	„
12	C2
Comm. return	C14

Jumpersettings

Jumpers (1 - 12) can be set for make (NO) or brake (NC) indication-outputs.



P2 Cableconnection to Alarmcard LS-12

To remove the circuitboard: remove the front frame and the front panel, then gently pull the circuitboard out of the case. The terminal blocks can be removed with a screwdriver. (Gently bend against the plastic case)

Note: The terminal blocks are of plug-in type.

LARMIA CONTROL AB

POSTADDRESS
Box 83
SE-191 22 Sollentuna
Sweden

BESÖKSADDRESS
Visiting address
Aniaraplatsen 4, 3tr

LEVERANSADDRESS
Shipping address
Allfarvägen 3
SE-191 47 Sollentuna

TELEFON
Telephone
08-444 53 00
+46 8 444 53 00

TELEFAX
Facsimile
08-444 53 19
+46 8 444 53 19

EMAIL
Info@larmia.se
Website
www.larmia.se